

FIG. 1




FIG.2




FIG. 3




FIG. 4

Assigned Telephone Number	User ID	Password	Destination Address (Priority 1) LF	Destination Address (Priority 2) LF	Destination Address (Priority 3) LF	Destination Address (Priority 4) LF	Destination Address (Priority 5) LF
050-xxxx-	user-a	*****	x.x.x.x	03-xxxx-	070-xxxx-	Null	Null
050-yyyy-	user-b	*****	y.y.y.y	090-yyyy-	Null	Null	Null
...							

125a

Assigned Tel. Number	Terminal ID
050-xxxx-	U1234-5678
...	

125b

BEST AVAILABLE COPY

FIG.5

Assigned Telephone Number	User ID	Password	Destination Address (Priority 1) LF	Destination Address (Priority 2) LF	Destination Address (Priority 3) LF	Destination Address (Priority 4) LF	Destination Address (Priority 5) LF
050-xxxx-	user-a	*****	x.x.x.x	1 03-xxxx-	070-xxxx-	Null	Null

125a


Destination Address (Priority 1) LF	Destination Address (Priority 2) LF	Destination Address (Priority 3) LF	Destination Address (Priority 4) LF
x.x.x.x	1 x1.x1.x1.x1	x2.x2.x2.x2	x3.x3.x3.x3

125c

FAX 番号: 045-228-0266


BEST AVAILABLE COPY

FIG. 7




BEST AVAILABLE COPY

FIG. 8



BEST AVAILABLE COPY

FIG. 9



BEST AVAILABLE COPY